



Introduction to Calibration




Presented to you by:
ArmStrong SIG
Ian Lo / Ryan Pang

4/6/2025 – Intern Training

Outline

- 1. What is a Frame?
- 2. Camera Model
- 3. Calibration Concepts
- 4. Homogeneous Transformation Matrix
- 5. Eye-to-Hand Calibration (3 DoF)
- 6. Demonstration






01

What is a Frame

- 1. What is a Frame?
- 2. Camera Model
- 3. Calibration Concepts
- 4. Homogeneous Transformation Matrix
- 5. Eye-to-Hand Calibration (3 DoF)
- 6. Demonstration

What is a Frame?



A frame is the reference point to which every other coordinate point is defined

Let's define some points on the grid:
world, camera, object


Then, with respect to the **world**:

Camera: (1,6) (1 units on x axis, 6 units on y)

Object: (6,4)

This is in the "world frame"


What is a Frame?



Similarly, with respect to the **camera**:
World: (-1,-6)
Object: (5,-2)

This is the “**camera** frame”

What is a Frame?



And with respect to the **object**:



World: $(-6, -4)$

Camera: $(-5, 2)$

This is the “**object** frame”

Notation:

$$H_b^a$$




Interpretation	Meaning	Use case
Transform interpretation	$H_b^a \cdot \overrightarrow{p_b} = \overrightarrow{p_a}$	You have a point in frame b , and you want to express it in frame a
Pose interpretation	H_b^a is the pose of frame b in reference frame a	Frame b is located and oriented relative to frame a

Notation:

$$H_b^a$$


Interpretation	Meaning	Use case
Transform interpretation	$H_b^a \cdot \overrightarrow{p_b} = \overrightarrow{p_a}$	You have a point in frame b , and you want to express it in frame a
Pose interpretation	H_b^a is the pose of frame b in reference frame a	Frame b is located and oriented relative to frame a



*Q: A camera has **detected** an object and output its coordinates **relative to the camera frame**. Which matrix correctly express this relationship?*

H_B^A or H_A^B

A: H_B^A because we want to express the object's pose (frame B) in the camera's frame (frame A).




02

Camera Model

- 1. What is a Frame?
- **2. Camera Model**
- 3. Calibration Concepts
- 4. Homogeneous Transformation Matrix
- 5. Eye-to-Hand Calibration (3 DoF)
- 6. Demonstration


Camera Model

The resulted orientation angles and acceleration vectors share the coordinate system with the depth sensor.





1. The positive x-axis points to the right.
2. The positive y-axis points down.
3. The positive z-axis points forward


Image
Coordinate
Frame



Object 3D Coordinates (in camera frame)
→ relative to the projection center C



The Camera Frame




Make sure you **align** the depth camera's:

1. Depth frame
2. Color frame

Before you read the depth of a point from a RGB image

Coordinate system of Intel® RealSense™ Depth Cameras (D435)

```
1 import pyrealsense2 as rs
2 import cv2 as cv
3 import numpy as np
4
5 pipeline = rs.pipeline()
6
7 cfg = rs.config()
8 cfg.enable_stream(rs.stream.depth, 640, 480, rs.format.z16, 30)
9 cfg.enable_stream(rs.stream.color, 640, 480, rs.format.bgr8, 30)
10
11 # Align depth to color
12 align_to = rs.stream.color
13 alignedFs = rs.align(align_to)
14
15 profile = pipeline.start(cfg)
16
17 try:
18     while True:
19         fs = pipeline.wait_for_frames()
20         aligned_frames = alignedFs.process(fs)
21
22         color_frame = aligned_frames.get_color_frame()
23         depth_frame = aligned_frames.get_depth_frame()
24
25         if not depth_frame or not color_frame:
26             continue
27
28         color_image = np.asanyarray(color_frame.get_data())
29         depth_image = np.asanyarray(depth_frame.get_data())
30
31         # Normalize the depth image for display
32         depth_colormap = cv.applyColorMap(cv.convertScaleAbs(depth_image, alpha=0.03), cv.COLORMAP_JET)
33
34         # Stack both images horizontally
35         images = np.hstack((color_image, depth_colormap))
36
37         # Display the result
38         cv.imshow('Aligned Frames', images)
39
40         if cv.waitKey(1) & 0xFF == ord('q'):
41             break
42 finally:
43     pipeline.stop()
44     cv.destroyAllWindows()
45
46
```




03

Calibration Concepts

- 1. What is a Frame?
- 2. Camera Model
- **3. Calibration Concepts**
- 4. Homogeneous Transformation Matrix
- 5. Eye-to-Hand Calibration (3 DoF)
- 6. Demonstration

Robot Frame

ROS



Forward Kinematics:

- *Known Joint Angles* → *Calculate EE coordinate*

Inverse Kinematics:

- *?*

Inverse Kinematics:


- *Known EE coordinate* → *Find Joint Angles*

The robot's **base frame** is the same as that of the **world frame**, at (0,0,0)

The **end effector** has its own frame

By using the robot's **forward kinematics**, we can find the position of the end effector with respect to the base.

Camera Calibration Concept



Problem:

Given that the **camera** knows the position of an **object**, we don't know what is its coordinate in the robot base frame.

The camera and robot base have different frames

Calculate the position of the **camera** w.r.t. the **robot base** frame.


Then we can command the robot to move and manipulate according to what camera sees.

Hand-Eye Calibration in Practice


The gripper's pose in robot base frame is known.

Q: What is the name of this process?


A: Forward Kinematics



Pose of some object (AprilTag) in camera frame is known using some software.



$${}^cH_t = \begin{bmatrix} 0.043 & 0.999 & -0.003 & 75 \\ -0.743 & 0.034 & 0.668 & 128 \\ 0.667 & -0.027 & 0.744 & 525 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$



04

Homogeneous Transformation Matrix

- 1. What is a Frame?
- 2. Camera Model
- 3. Calibration Concepts
- **4. Homogeneous Transformation Matrix**
- 5. Eye-to-Hand Calibration (3 DoF)
- 6. Demonstration

Tutorial on Transformation

- A 3D rigid **transformation** is composed of a **rotation** and a **translation**.
- The **rotation** can be expressed by a 3*3 matrix, and the **translation** can be expressed by a 3-element vector.


$$\mathbf{R} = \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix}$$

$$\mathbf{t} = \begin{bmatrix} x \\ y \\ z \end{bmatrix}$$

- The **homogeneous transformation matrix** is a 4*4 matrix in this form:

$$\mathbf{H} = \begin{bmatrix} \mathbf{R} & \mathbf{t} \\ 0 & 1 \end{bmatrix} = \begin{bmatrix} r_{11} & r_{12} & r_{13} & x \\ r_{21} & r_{22} & r_{23} & y \\ r_{31} & r_{32} & r_{33} & z \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

- A **pose** is composed of a **position** and an **orientation**, which can be analogized to the translation and rotation. So, a pose can be expressed by a transformation matrix.
- Example: Rotate $p = [1,0,0]$ around z-axis for 45 degrees to get p_1 and translate p_1 by $[0,0,1]$ to get p_2 .




$$\begin{aligned}
 \mathbf{p} &= [1 \ 0 \ 0]^T \\
 \mathbf{t} &= [0 \ 0 \ 1]^T \\
 \mathbf{R} &= \begin{bmatrix} \frac{\sqrt{2}}{2} & -\frac{\sqrt{2}}{2} & 0 \\ \frac{\sqrt{2}}{2} & \frac{\sqrt{2}}{2} & 0 \\ 0 & 0 & 1 \end{bmatrix} \\
 \mathbf{p}_1 &= \mathbf{R}\mathbf{p} \\
 &= \begin{bmatrix} \frac{\sqrt{2}}{2} & -\frac{\sqrt{2}}{2} & 0 \\ \frac{\sqrt{2}}{2} & \frac{\sqrt{2}}{2} & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix} \\
 &= \begin{bmatrix} \frac{\sqrt{2}}{2} \\ \frac{\sqrt{2}}{2} \\ 0 \end{bmatrix} \\
 \mathbf{p}_2 &= \mathbf{p}_1 + \mathbf{t} \\
 &= \begin{bmatrix} \frac{\sqrt{2}}{2} & \frac{\sqrt{2}}{2} & 1 \end{bmatrix}
 \end{aligned}$$

$[1 \ 0 \ 0]^T$ is under the **old** frame

From equation $\mathbf{p}_{new} = \mathbf{R}\mathbf{p}_{old}$, we know that \mathbf{R} is in a form of a matrix that can transform a point from old frame to new frame, \mathbf{H}_{old}^{new}

For \mathbf{R}_{old}^{new} , it should be in form of $\begin{bmatrix} -V_x & - \\ -V_y & - \\ -V_z & - \end{bmatrix}$, which

$[-V_x -]$ is a unit vector representing how old x-axis projects onto the new coordinate system. Or, you can understand it



Homogeneous Transformation Matrix

In homogeneous form:

Note that in 3D homogeneous coordinate system, we append a '1' after column vector $[x, y, z]$ to make it homogeneous.



$$H = \begin{bmatrix} R & t \\ 0 & 1 \end{bmatrix}$$
$$H^{-1} = \begin{bmatrix} R^T & -R^T * T \\ 0 & 1 \end{bmatrix} = H^T$$

$$\begin{bmatrix} x' \\ y' \\ z' \\ 1 \end{bmatrix} = \begin{bmatrix} R & t \\ 0 & 1 \end{bmatrix} \begin{bmatrix} x \\ y \\ z \\ 1 \end{bmatrix}$$
$$= \begin{bmatrix} \frac{\sqrt{2}}{2} & -\frac{\sqrt{2}}{2} & 0 & 0 \\ \frac{\sqrt{2}}{2} & \frac{\sqrt{2}}{2} & 0 & 0 \\ 0 & 0 & 1 & 1 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 1 \end{bmatrix}$$
$$= \begin{bmatrix} \frac{\sqrt{2}}{2} \\ \frac{\sqrt{2}}{2} \\ 1 \\ 1 \end{bmatrix}$$


Hand-Eye Calibration

- Terms

- The base of robotic arm: *base, robot*
- The hand of robotic arm: *end-effector (ee), gripper, tool, hand*
- The camera: *camera, eye, sensor*
- The target object or the calibration board: *obj, target, cal*



- Eye-in-Hand: camera is attached on the hand
- Eye-to-Hand: camera is separate from the robot and stationary



05

Eye-to-Hand Calibration

- 1. What is a Frame?
- 2. Camera Model
- 3. Calibration Concepts
- 4. Homogeneous Transformation Matrix
- **5. Eye-to-Hand Calibration (3 DoF)**
- 6. Demonstration

Eye-to-Hand Calibration

- The AprilTag will be attached on the gripper.
- There is an unknown transformation from camera to the robot base T_c^b
- There is an constant transformation from the target to the gripper
 - In common practice, we don't care about this transformation because it won't be involved in the calculation. But for simplification, we measure this matrix on Dobot and use a simpler method to calibrate.

$${}^gT_t = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & -1 & 0 & 0 \\ 0 & 0 & -1 & 140 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Eye-to-Hand Calibration


- We are to find out the transformation from camera to robot base so that we can bring a point from camera frame to robot base frame.


- $T_c^b \cdot \vec{p}_c = \vec{p}_a$

- The transformation follows a loop:

- $T_c^b = T_g^b \cdot T_c^g \cdot T_t^t = T_g^b \cdot T_c^g \cdot T_t^{c^{-1}}$

- The camera obtains T_t^c and its inverse will be T_c^t





Eye-to-Hand Calibration


1. **Data Collection:** Record transformations of T_t^c and T_g^b from various robot poses
2. **Calculation:** Get transformations of T_c^t using matrix inverse. Calculate the T_c^b transformation matrices.
3. **Average:** Derive the **rotation angles** and **translations** from the matrices and take the averages for them.
4. Save the final transformation in any form you like as a file for later use.

Q:

$$H_c^b = H_g^b ? H_t^g ? H_c^t$$

A:

$$H_c^b = H_g^b @ H_t^g @ H_c^t$$





06



Demonstration

- 1. What is a Frame?
- 2. Camera Model
- 3. Calibration Concepts
- 4. Homogeneous Transformation Matrix
- 5. Eye-to-Hand Calibration (3 DoF)
- **6. Demonstration**

Using calibration_simplified.py

1. Run the program, wait for Dobot to calibrate itself.
2. Unlock Dobot and move to a different pose such that AprilTag can be detected by the camera.
3. Press Enter at camera view window to record the transformation (T_t^c and T_g^b)
4. Repeat step 2 and 3 to collect more data.
5. Press 'q' to calculate, average and save the transformation.
6. Check "config/camera_to_robot_transformation.yaml"

Demonstration



```
pwsh in dobot_magician_cont x + v
> python .\calibration\calibration_simplified.py
Homing the robotic arm for calibration...
Attach the AprilTag 15.3cm above the gripper and make the x-axes aligned before calibration.
At the camera window, press Enter to record data, press 'q' to quit and calculate the transformation.
```

Validation of Calibration

Check whether the robotic arm could reach the point that the camera sees.

1. Use AprilTag and camera to obtain a position from camera view and this position should be reachable by the arm. (Same as the calibration)
2. Load the transformation you just saved. Apply it to the AprilTag's position to get the coordinate in robot base frame.

Homogeneous


$${}^bH_c \cdot \mathbf{P}_c = \mathbf{P}_b$$

Cartesian

$$R \cdot \mathbf{p}_c + \mathbf{t} = \mathbf{p}_b$$

3. Move the gripper to the position, see if it goes to the correct place.

Demonstration



Practice makes perfect 😊

You will find TODO sections in the provided programs


- *calibration_simplified.py*
- *calibration_validate.py*

```
if len(cHt_list) >= 1:
    #####
    # TODO: Your Code Here
    # Get the inverse of each cHt matrix
    #####

    # gripper to tag transformation (x-axes aligned)
    # [1, 0, 0, 30]
    # [0, -1, 0, 0]
    # [0, 0, -1, 153]
    # [0, 0, 0, 1]
    # tag size = 0.0792 meters

    #####
    # TODO: Your Code Here
    # Define the gripper to tag transformation matrix (gHt)
    #####

    #####
    # TODO: Your Code Here
    # Calculate bHc_list, which is the transformation from base to camera frame
    #####
```



<https://connecthkuhk.sharepoint.com/:u:/s/RoboticArmSIG/EROQGSHeXNpAvu0l3XcMbj0BHbxLpqIoJBPJN1aFICBVXw?e=e0n1y3>

<https://shorturl.at/SLoJ2>